lan	ne:l	DEQ Agency	/ Interest (AI) #:
lie	nt:		
Proj	ject Name:		
Pro	ject Number:		
	MAINTENANCE SCHEDULE – I		
	WEEKLY MAINTE		TASKS
	Task	When Complete	Comments
1.	Check oil level (if oil seal) and condition for the Liquid		
2.	Ring Pump (LRP). Check for water in oil sight gauge; drain off if necessary		
۷.	(if oil seal).		
3.	Observe scavenge line flow for the LRP.		
4.	Check the operation of the transfer pumps.		
5.	Note the backpressure of the Stripper blower.		\
6.	Note backpressure of Air/Oil Demister filter. Should		
	be (<) 4 PSIG. Replace as required (if oil seal).		
7.	Monitor the operation of the Stripper effluent pump		
	and note the reading of the totalizing flow meter.		
8.	Drain solids from the bottom of AWS-1.		
9.	Check bag filter and carbon pressures. Change bags as		
	necessary to maintain flow. Note the differential		
10.	pressures from vessel to vessel. Check levels on storage tanks. Empty, as necessary.		
11.	For systems with Liquid carbon, check backpressure and flow rate through totalizer. If flow rate is less than		
	influent flow rate or 5 GPM, whichever is greater, back		
	flush carbon vessel by switching the influent and		
	effluent lines on the vessel. Allow 2-3 cycles and return		
	hoses to original positions.		
12.	Check all return lines from AWS-3 (if oil seal) and		
	carbon tanks. Make sure they free flow back to the		
	AWS-1 tank.		
13.	Check air readings from each extraction line to calculate		
	equivalent COC removal.		
Not	es:		

Date:____

	Project Number:				
MAINTENANCE SCHEDUL					
MONTHLY MA		CE TASKS			
Task	✓ When Complete	Comments			
Check transfer pumps and conductivity probes for signs of Mineral deposits and clean if necessary.					
Grease the bearings on the Liquid Ring Pump (LRP) (every other month). Give each grease fitting 2 shots of grease.					
Check and clean conductivity level probe rods in AWS-1.					
Check and clean sight glass gauge for silt, iron, and calcium build-up. Replace sight glass if needed.					
Inspect the OWS packing.					
Check all hoses for deterioration.					
Inspect the aeration tubes in the stripper.					
Clean radiator of dust, dirt, leaves, etc (if oil seal).					
Tighten nuts and bolts on liquid ring flanges and hose clamps.					
Check all hoses for deterioration.					
Inspect walls, motors, fans, components for any damages or corrosion.					
Check the separation tanks AWS-1, AWS-2 and AWS-3 for solids or scaling.					
s:					
	Check transfer pumps and conductivity probes for signs of Mineral deposits and clean if necessary. Grease the bearings on the Liquid Ring Pump (LRP) (every other month). Give each grease fitting 2 shots of grease. Check and clean conductivity level probe rods in AWS-1. Check and clean sight glass gauge for silt, iron, and calcium build-up. Replace sight glass if needed. Inspect the OWS packing. Check all hoses for deterioration. Inspect the aeration tubes in the stripper. Clean radiator of dust, dirt, leaves, etc (if oil seal). Tighten nuts and bolts on liquid ring flanges and hose clamps. Check all hoses for deterioration. Inspect walls, motors, fans, components for any damages or corrosion. Check the separation tanks AWS-1, AWS-2 and AWS-3 for solids or scaling.	Check transfer pumps and conductivity probes for signs of Mineral deposits and clean if necessary. Grease the bearings on the Liquid Ring Pump (LRP) (every other month). Give each grease fitting 2 shots of grease. Check and clean conductivity level probe rods in AWS-1. Check and clean sight glass gauge for silt, iron, and calcium build-up. Replace sight glass if needed. Inspect the OWS packing. Check all hoses for deterioration. Inspect the aeration tubes in the stripper. Clean radiator of dust, dirt, leaves, etc (if oil seal). Tighten nuts and bolts on liquid ring flanges and hose clamps. Check all hoses for deterioration. Inspect walls, motors, fans, components for any damages or corrosion. Check the separation tanks AWS-1, AWS-2 and			

Project Number:			
	MAINTENANCE SCHEDUI	LE – LIQU	ID RING PUMP SYSTEM
	QUARTERLY M	IAINTENA	ANCE TASKS
	Task	When Complete	Comments
1.	Chemically descale transfer pump and conductivity probes and discharge check valve.		
2.	Clean Liquid Ring Pump (LRP) oil strainer for oil seal and wye strainer for water seal.		
3.	Check LRP system piping for leaks.		
1.	With power off, perform a wire pull test and tighten all electrical connections in the control panel.		
5.	With the power off, check all electrical connections at the motor junction boxes. Check the wires for corrosion.		
5.	Grease motors.		
7.	Test high level and high temperature sensors and alarms.		
3.	Test E stop button.		
).	Calibrate vacuum transducer. With vacuum off, check and set the zero setting. With the vacuum running at a constant vacuum. Check and adjust the span screw, clockwise to adjust reading higher.		
10.	General structure inspection. Door, ceiling, wall panels for leaks or damage.		
ote	es:		

Date:_____

	MAINTENANCE SCHEDULE -	PUMP AND TR	REAT SYSTEM
	WEEKLY MAINTI	ENANCE TASK	S
	Task	When Complete	Comments
14. Cł	heck operation of down well pumps.		
15. Cł	heck the operation of the transfer pumps.		
	Ionitor the operation of the Stripper effluent pump and ote the reading of the totalizing flow meter.		
ne	heck bag filter and carbon pressures. Change bags as ecessary to maintain flow. Note the differential ressures from vessel to vessel.		
18. Cl	heck levels on storage tanks. Empty, as necessary.		
an in flu ef	or systems with Liquid carbon, check backpressure and flow rate through totalizer. If flow rate is less than affluent flow rate or 5 GPM, whichever is greater, back sush carbon vessel by switching the influent and affluent lines on the vessel. Allow 2-3 cycles and eturn hoses to original positions.		
T-4	_		
Notes:	:		

ient:		
Project Name:		
Project Number:		
MAINTENANCE SCHEDULE – PUMP AND TREAT SYSTEM		
MONTHLY MA	INTENAN	CE TASKS
Task	When Complete	Comments
13. Check transfer pumps and conductivity probes for signs of Mineral deposits and clean if necessary.		
14. Check and clean conductivity level probe rods in sump.		
15. Check and clean sight glass gauge for silt, iron, and calcium build-up. Replace sight glass if needed.		
16. Inspect the OWS packing.		
17. Check all hoses for deterioration.		
18. Check all hoses for deterioration.		
19. Inspect walls, motors, fans, components for any damages or corrosion.		
20. Gauge wells to ensure pump intake is set at appropriate depth.		
Jotes:		1
Notes:		

	MAINTENANCE SCHEDU QUARTERLY I		
	Task	When Complete	Comments
1.	Clean OWS and packing.		
2.	Pull wires in control panel to inspect for damage.		
3.	Fill OWS and Air Stripper and restart system.		
4.	Inspect conductivity probes and clean if necessary.		
5.	Clean bag filter housing.		
6.	List volume of waste fluid and sludge materials generated in comments section.		
tes: _			

MAINTENANCE SCHEDULE – POSITIVE DISPLACEMENT PUMP SYSTEM			
	WEEKLY MA		NCE TASKS
	Task	When Complete	Comments
1.	Check gear oil, temperature and condition of the PD vacuum pump, note any excessive		
2.	temperature rise, oil consumption or vibration. Check the operation of the transfer pumps.		
3.	Check the backpressure of the Stripper blower.		
4.	Monitor the operation of the stripper effluent pump and note the reading of the totalizing flow meter.		
5.	Drain solids from the bottom of AWS-1.		
6.	Check AWS-1inlet strainer. Strainer can be removed after the first month of operation.		
7.	Check, and drain/flush solids from the bottom of AWS-1tank.		
8.	Check levels on storage tanks. Empty as necessary.		
9.	Check bag filter and carbon pressures. Change bags as necessary to maintain flow. Note the differential pressures from vessel to vessel.		
10.	For systems with Liquid carbon, check backpressure and flow rate through totalizer. If flow rate is less than influent flow rate or 5 GPM, whichever is greater, back flush carbon vessel by switching the influent and effluent lines on the vessel. Allow 2-3 cycles and return hoses to original positions.		
11.	Check air readings from each extraction line to calculate equivalent COC removal.		

Task eck transfer pumps for signs of mineral posits and clean if necessary. ease the bearings on the liquid ring pump very other month). Give each grease fitting 2 ots of grease. eck and clean conductivity level probe rods in WS-1 and sump. eck and clean sight glass gauge for silt, iron, d calcium build-up. Replace sight glass if eded.	When Complete	Comments
posits and clean if necessary. ease the bearings on the liquid ring pump very other month). Give each grease fitting 2 ots of grease. eck and clean conductivity level probe rods in WS-1and sump. eck and clean sight glass gauge for silt, iron, d calcium build-up. Replace sight glass if eded.		
ease the bearings on the liquid ring pump very other month). Give each grease fitting 2 ots of grease. eck and clean conductivity level probe rods in WS-1 and sump. eck and clean sight glass gauge for silt, iron, d calcium build-up. Replace sight glass if eded.		
very other month). Give each grease fitting 2 obts of grease. eck and clean conductivity level probe rods in WS-1 and sump. eck and clean sight glass gauge for silt, iron, d calcium build-up. Replace sight glass if eded.		
ots of grease. eck and clean conductivity level probe rods in WS-1 and sump. eck and clean sight glass gauge for silt, iron, d calcium build-up. Replace sight glass if eded.		
WS-1 and sump. eck and clean sight glass gauge for silt, iron, d calcium build-up. Replace sight glass if eded.		
eck and clean sight glass gauge for silt, iron, d calcium build-up. Replace sight glass if eded.		
d calcium build-up. Replace sight glass if eded.		
eded.		
1 01170 11		
spect the OWS packing.		
spect the aeration tubes in the Stripper.		
ghten nuts and bolts on flanges and hose		
mps.		
eck all hoses for deterioration.		
spect walls, motors, fans, and components for		
y damage or corrosion.		
eck the separation tank for solids or scaling.		
	ghten nuts and bolts on flanges and hose mps. eck all hoses for deterioration. epect walls, motors, fans, and components for y damage or corrosion.	ghten nuts and bolts on flanges and hose mps. eck all hoses for deterioration. epect walls, motors, fans, and components for y damage or corrosion.

			DISPLACEMENT PUMP SYSTEM	
	QUARTERLY N Task	☑ When	Comments	
1.	Chemically descale transfer pump and conductivity probes and discharge check valve.	Complete		
2.	Clean all wye-strainers.			
3.	Check PD blower vacuum system piping for leaks.			
4.	With power off, perform a wire pull test and tighten all electrical connections in the control panel.			
5.	With the power off, check all electrical connections at the motor junction boxes. Check the wires for corrosion.			
6.	Check gear oil level, top off as needed.			
7.	Refer to PO O&M manual for greasing and oil service. Transfer pump and air stripper blower motors have sealed bearings and do not require greasing.			
8.	Test high level and high temperature sensors and alarms.			
9.	Test the Stop button.			
10.	Calibrate vacuum transducer. With vacuum off, check and set the zero setting. With the vacuum running at a constant vacuum. Check and adjust the span screw, clockwise to adjust reading higher.			
11.	General structure inspection. Inspect door, ceiling, and wall panels for leaks or damage.			
	check and set the zero setting. With the vacuum running at a constant vacuum. Check and adjust the span screw, clockwise to adjust reading higher. General structure inspection. Inspect door,			

Date:

e Name:		LDEQ	Agency Interest (AI) #:
C Client:			
C Project N	ame:		
C Project N	umber:		
	MAINTENANCE SCHED	ULE – AIR	STRIPPER CLEANING
	QUARTERLY N	MAINTEN	ANCE TASKS
	Task	When Complete	Comments
7.	Clean AWS-1.		
8.	Clean AWS-2 and transfer lines.		
9.	Clean OWS and packing.		
10.	Clean Air Stripper and aeration tubes.		
11.	Clean air stripper sump.		
12.	Fill AWS-1, AWS-2, OWS, and Air Stripper and restart system.		
	Inspect conductivity probes and clean if necessary.		
14.	Clean bag filter housing.		
15.	List volume of waste fluid and sludge materials generated in comments section.		
Notes:			
Signature Date:	e:		

MAINTENANCE S	CHEDULE	2 - SVE SYSTEM
WEEKLY MA	AINTENAN	CE TASKS
Task	When Complete	Comments
Check gear oil, temperature and condition of the vacuum pump, note any excessive temperature rise, oil consumption or vibration.		
. Check the operation of the transfer pumps.		
. Check AWS-1 inlet strainer. Strainer can be removed after the first month of operation.		
. Check, and drain/flush solids from the bottom of AWS-1tank.		
res:		

C Project Number:				
			LE - SVE SYSTEM	
	MONTHLY		ANCE TASKS	
	Task	✓ When Complete	Comments	
•	Check transfer pumps and conductivity probes for signs of mineral deposits and clean if necessary.			
2.	Grease the bearings on the motor (every other month). Give each grease fitting 2 shots of grease.			
3.	Check and clean conductivity level probe rods in AWS-1.			
4.	Check and clean sight glass gauge for silt, iron, and calcium build-up.			
5.	Check vacuum gauges to ensure that max. Vacuum is not exceeded.			
6.	Inspect air filter on optional CFM gauge for moisture. Drain high vacuum switch.			
7.	proper operation. Check all wiring for loose connections.			
8.	Tighten nuts and bolts on flanges and hose clamps.			
9.	Check moisture separator for pressure drop across filter/moisture demister(pressure drop should not exceed 6" H20 (0.44 in Hg) under normal operating conditions.)			
10.	Inspect walls, motors, fans, components for any damages or corrosion.			
No	tes:			

Date:_____

Name:LDEQ Agency Interest (AI) #:							
lient:							
ect Name:							
C Project Number:							
MAINTENANCE SCHEDULE - SVE SYSTEM							
QUARTERLY MAINTENANCE TASKS							
Task	✓ When Complete	Comments					
Chemically descale transfer pump and conductivity probes and discharge check valve optional.							
Clean all wye-strainers.							
Check vacuum system piping for leaks.							
With power off, perform a wire pull test and tighten all electrical connections in the control panel.							
With the power off, check all electrical connections at the motor junction boxes. Check the wires for corrosion.							
Check gear oil level, top off as needed optional.							
Refer to PO O&M manual for greasing and oil service. Transfer pump motors have sealed bearings and do not require greasing.							
Test high level and high temperature sensors and alarms.							
Test the Stop button.							
Calibrate vacuum transducer. With vacuum off, check and set the zero setting. With the vacuum running at a constant vacuum. Check and adjust the span screw, clockwise to adjust reading higher.							
General structure inspection. Inspect door, ceiling, and wall panels for leaks or damage.							
S:							
	ct Name: Ct Number: MAINTENANCE SO QUARTERLY M Task Chemically descale transfer pump and conductivity probes and discharge check valve optional. Clean all wye-strainers. Check vacuum system piping for leaks. With power off, perform a wire pull test and tighten all electrical connections in the control panel. With the power off, check all electrical connections at the motor junction boxes. Check the wires for corrosion. Check gear oil level, top off as needed optional. Refer to PO O&M manual for greasing and oil service. Transfer pump motors have sealed bearings and do not require greasing. Test high level and high temperature sensors and alarms. Test the Stop button. Calibrate vacuum transducer. With vacuum off, check and set the zero setting. With the vacuum running at a constant vacuum. Check and adjust the span screw, clockwise to adjust reading higher. General structure inspection. Inspect door, ceiling, and wall panels for leaks or damage.	t:					

Date:

	Project Number:						
MAINTENANCE SCHEDULE – OZONE SPARGE SYSTEM WEEKLY MAINTENANCE TASKS							
	Task	When Complete	Comments				
	Check O2, O3, oxygen delivery pump, and air flow booster	Complete					
	contactors.						
	Check the O3 production.						
	Check the O2 purity for proper production of O3.						
	Monitor the reactor pressure and O2 flow and compare						
	against the manufacturers specifications.						
	Check O2 compressor inlet air filters. If needed						
	clean or replace.						
	Check air flow booster compressor inlet air filters. If neede						
	clean or replace.						
	Check water separator for proper function and check filters						
	and O-ring. If needed clean or replace.						
	Check each ozone injection point for ozone leaks.						
	Inspect enclosure intake filters.						
	Test all auto drains.						
	Inspect HVAC and/or ventilation filters and louvers.						
	Test operation of heaters and exhaust fans.						
3.	Cycle through all ozone points, check, and record pressure						
	and flow at each point. If high breakthrough pressures are						
	present injection point may be plugged of scaled over.						
	Check system lag times for proper settings.						
	Inspect integrity of hoses, fittings, piping, and valves. Inspect O2 moisture indicators. Blue indicates that						
).	no moisture is present, pink or white indicates that moisture						
	is present. If moisture indicator is pink or white disable						
	ozone production and contact factory.						
	Check valve run times to insure system is running properly						
	, , ,						
1.	on each point.						
	on each point. Check to see that the product type (O2, O3, etc) is properl						

Date:_____

MAINTENANCE SCHEDULE – OZONE SPARGE SYSTEM				
	MONTHLY I	WAINTEN. When Complete	ANCE TASKS Comments	
	Check pressure gauge to ensure that maximum pressure is not exceeded.	Ompress		
	Check motor amp draw. Check all switches for proper operation. Check all wiring for loose connections.			
3.	Check for loose fittings and bolts.			
4.	Check functionality of check valve.			
	If applicable, check oil level and condition. Replace as recommended by manufacturer.			
otes:	:			

MAINTENANCE SCHEDULE – OZONE SPARGE SYSTEM QUARTERLY MAINTENANCE TASKS					
Task	When Complete	Comments			
Check Ozone Sparge system piping for leaks.					
Inspect all plastic fitting in system for integrity.					
With power off, perform a wire pull test and tighten all electrical connections in the control panel.					
With the power off, check all electrical connections at the motor junction boxes. Check the wires for corrosion.					
Check compressor oil level, top off as needed.					
Refer to O&M manual for greasing and oil service.					
Test high level and high temperature sensors and alarms.					
Test the Stop button.					
General structure inspection. Inspect door, ceiling, and wall panels for leaks or damage.					
otes:					

Note: Non-routine maintenance for the 6-month and 12-month service kits should be conducted as a System Repair (SR) not routine Operation & Maintenance (O&M).